



USER MANUAL

Read the manual carefully and ensure you have fully understood its contents before operating this device for the first time.

English

Safety Instructions



This symbol indicates high voltage is present inside. It is dangerous to make any kind of contact with any inside part of this product.



This symbol alerts you that important literature concerning operation and maintenance has been included with this product.



CAUTION

RISK OF SHOCK
ELECTRIC



CAUTION: To reduce the risk of electric shock, do not remove cover (or back). No user serviceable parts inside. Refer servicing to qualified service personnel.

Waste Electrical and Electronic Equipment-WEEE

Attention: users in European Union private households



This marking on the product or on its packaging illustrates that, under European Directive 2012/19/EU governing used electrical and electronic appliances, this product may not be disposed of with normal household waste. You are responsible for disposal of this equipment through a designated waste electrical and electronic equipment collection. To determine the locations for dropping off such waste electrical and electronic equipment, contact your local government office, the waste disposal organization that serves your household or the store at which you purchased the product.

End of Life Directives-Recycling



Your new Public Information Display contains several materials that can be recycled for new users.

Please dispose of according to all Local, State, and Federal laws.

End-of-Life Disposal

Your new Public Information Display contains materials that can be recycled and reused. Specialized companies can recycle your product to increase the amount of reusable materials and to minimize the amount to be disposed of.

Please find out about the local regulations on how to dispose of your old display from your local dealer.

For customers in Canada and U.S.A.

This product may contain lead and/or mercury. Dispose of in accordance to local-state and federal regulations. For additional information on recycling contact www.eia.org (Consumer Education Initiative)

Important Safety Instructions

Read and follow these instructions when connecting and using your Public Information Display.

- Unplug the display if you are not going to use it for an extensive period of time.
- Unplug the display if you need to clean it with a slightly damp cloth. The screen may be wiped with a dry cloth when the power is off. However, never use alcohol, solvents or ammonia-based liquids.
- Consult a service technician if the display does not operate normally when you have followed the instructions in this manual.
- The casing cover should be opened only by qualified service personnel.
- Keep the display out of direct sunlight and away from stoves or any other heat sources.
- Remove any object that could fall into the vents or prevent proper cooling of the display's electronics.
- Do not block the ventilation holes on the cabinet.
- Keep the display dry. To avoid electric shock, do not expose it to rain or excessive moisture.
- If turning off the display by detaching the power cable, wait for 6 seconds before re-attaching the power cable for normal operation.
- To avoid the risk of shock or permanent damage to the set, do not expose the display to rain or excessive moisture.
- When positioning the display, make sure the power plug and outlet are easily accessible.
- **IMPORTANT:** Always activate a screen saver program during your application. If a still image in high contrast remains on the screen for an extended period of time, it may leave an 'after-image' or 'ghost image' on the front of the screen. This is a well-known phenomenon that is caused by the shortcomings inherent in LCD technology. In most cases the afterimage will disappear gradually over a period of time after the power has been switched off. Be aware that the after-image symptom cannot be repaired and is not covered under warranty.

Safeguards

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.

Safety Instructions

8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use cautiously when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. The batteries (batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
16. An all-pole MAINS SWITCH is used as the disconnect device, the location on the apparatus and the function of the switch shall be described, and the switch shall remain readily operable.



WARNING:

- To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- The batteries (batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
- The mains plug or appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- To prevent the spread of fire, keep candles or other open flames away from this product at all times.



- To prevent injury, this apparatus must be securely attached to the floor/wall in accordance with the installation instructions.

- The Class I apparatus shall be connected to a mains socket outlet with a protective earthing connection.

Never place a television set in an unstable location. A television set may fall, causing serious personal injury or death. Many injuries, particularly to children, can be avoided by taking simple precautions such as:

- Using cabinets or stands recommended by the manufacturer of the television set.
- Only using furniture that can safely support the television set.
- Ensuring the television set is not overhanging the edge of the supporting furniture.
- Not placing the television set on tall furniture (for example, cupboards or bookcases) without anchoring both the furniture and the television set to a suitable support.
- Not placing the television set on cloth or other materials that may be located between the television set and supporting furniture.
- Educating children about the dangers of climbing on furniture to reach the television set or its controls.

If your existing television set is being retained or relocated, the same considerations as above should be applied.

- This equipment is compliant with Class A of EN55032/CISPR 32. In a residential environment this equipment may cause radio interference.

CAUTION:

- These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.
- Excessive sound pressure from earphones and headphones can cause hearing loss. Adjustment of the equalizer to maximum increases the earphone and headphone output voltage and the sound pressure level. Therefore, to protect your hearing, adjust the equalizer to an appropriate level.
- FCC/CSA regulations state that any unauthorized changes or modifications to this equipment may void the user's authority to operate it.
- To prevent electric shock, match the wide blade of plug to the wide slot, and fully insert the plug.
- To prevent damage which may result in fire or electric shock hazard, do not expose this appliance to rain or moisture.
- The Socket-outlet should be installed near the apparatus and be easily accessible.

NOTE:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.



| | | |
|------|---|----|
| 1. | Unpacking and Installation | 1 |
| 1.1. | Unpacking | 1 |
| 1.2. | Package Contents..... | 1 |
| 1.3. | Installation Notes..... | 2 |
| 1.4. | Mounting on a Wall | 2 |
| 2. | Parts and Functions | 4 |
| 2.1. | Control Panel | 4 |
| 2.2. | Input/Output Terminals | 5 |
| 2.3. | Remote Control | 6 |
| 3. | Connecting External Equipment..... | 8 |
| 3.1. | Connecting External Equipment (DVD/VCR/VCD) | 8 |
| 3.2. | Connecting a PC | 8 |
| 3.3. | Connect USB | 9 |
| 4. | Operation..... | 10 |
| 4.1. | Media Player Introduction | 10 |
| 4.2. | PDF Reader Play | 12 |
| 4.3. | U player Autoplay Instructions..... | 14 |
| 4.4. | U Disk Files Playback and Copy Instructions..... | 15 |
| 4.5. | App Customization | 15 |
| 5. | OSD Menu..... | 16 |
| 5.1. | Navigating the OSD Menu | 16 |
| 5.2. | Operation on the OSD Menu..... | 17 |
| 6. | Compatibility of the USB Device | 22 |
| 7. | Input Mode | 25 |
| 8. | Cleaning and Troubleshooting..... | 27 |
| 8.1. | Cleaning | 27 |
| 8.2. | Troubleshooting | 28 |
| 9. | Technical Specifications | 30 |

This manual is for reference only, please refer to the actual machine.

1. Unpacking and Installation


1.1. Unpacking

- This product is packed in a carton, together with the standard accessories.
- Any other optional accessories will be packed separately.
- Move the display by at least two (2) adults.
- After opening the carton, ensure that the contents are complete and in good condition.

1.2. Package Contents

Please verify that you received the following items with your package content:


- LCD Display
- User Manual
- Remote Control with AAA Batteries
- Power Cord
- HDMI Cable



* The supplied power cord varies depending on destination.



User Manual



Remote Control and AAA Batteries



Power Cord



HDMI Cable

* Items may differ in different locations

* Display design and accessories may differ from the images shown.

NOTES:


- For all other regions, apply a power cord that conforms to the AC voltage of the power socket and has been approved by and complies with the safety regulations of the particular country.
- Keep the packaging materials appropriately after unpacking the product.

1.3. Installation Notes

- Only use the power cable provided with this product. If an extension cord is required, please consult your service agent.
- The product should be installed on a flat surface, or the product may tip over. Leave a space between the rear of the product and the wall for proper ventilation. Do not install the product in a kitchen, bathroom or a place exposed to moisture, failure to do so may shorten the life of the internal parts.
- Do not install the product where it is 3000m or higher in altitude. Failure to do so may result in malfunctions.

1.4. Mounting on a Wall

To mount this monitor onto a wall, you will have to obtain a standard wall-mounting kit (commercially available). We recommend using a mounting interface that complies with TUV-GS and/or UL1678 standard in North America.




1. Lay a protective sheet on a table, which was wrapped around the monitor when it was packaged, beneath the screen surface so as not to scratch the screen face.
2. Ensure you have all accessories for mounting this monitor (wall mount, ceiling mount, table stand, etc).
3. Follow the instructions that come with the base mounting kit. Failure to follow correct mounting procedures could result in damage to the equipment or injury to the user or installer. Product warranty does not cover damage caused by improper installation.
4. For the wall-mounting kit, use M6 mounting screws (having a length 10 mm longer than the thickness of the mounting bracket) and tighten them securely.

To prevent the monitor from falling:

- For wall or ceiling installation, we recommend installing the monitor with metal brackets which are commercially available. For detailed installation instructions, refer to the guide received with the respective bracket.
- To lessen the probability of injury and damage resulting from fall of the monitor in case of earthquake or other natural disasters, be sure to consult the bracket manufacturer for installation location.


Ventilation Requirements for enclosure locating

To allow heat to disperse, leave space between surrounding objects as shown in the diagram below.



2. Parts and Functions

2.1. Control Panel



NOTE:

The appearance and color of the product are subject to the material object. The picture is for reference only.

① [Power] button

Turn the display on or put the display to standby.

② [MUTE] button

Mute or reactivate the audio.

③ [INPUT] button

- Select an input source when OSD menu is off.

④ [++] button

- Increase the volume of the audio when OSD menu is off.
- Move to the right item or Increase the adjustment while OSD menu is on.

⑤ [--] button

- Decrease the volume of the audio when OSD menu is off.
- Move to the left item or decrease the adjustment while OSD menu is on.

⑥ [▲] button

Move the highlight bar up to adjust the selected item while OSD menu is on.

⑦ [▼] button

Move the highlight bar down to adjust the selected item while OSD menu is on.


⑧ [MENU] button

Enter next submenu when OSD menu is on, or to activate the OSD menu when OSD menu is off.

⑨ Remote control sensor and power status indicator

- Receive command signals from the remote control.
- Indicate the operating status of the display.

2.2. Input/Output Terminals




NOTE:

The appearance and color of the product are subject to the material object. The picture is for reference only.

- | | |
|--|---|
| <p>① AC IN AC power input from the wall outlet.</p> <p>② MAIN POWER SWITCH Switch the main power on/off.</p> <p>③ AUDIO IN Audio input for VGA source (3.5mm stereo phone).</p> <p>④ AUDIO OUT Audio output for external AV device.</p> <p>⑤ LAN Internet function.</p> <p>⑥ D-SUB (VGA IN) VGA video input.</p> <p>⑦ HDMI2 IN / ⑧ HDMI1 IN Connect to a source device via an HDMI cable.</p> <p>⑨ RS232 Receive command signals from the external RS232 device.</p> | <p>⑩ USB PORT Connect to a USB storage device.</p> <p>⑪ MICRO SD Connect your MICRO SD CARD</p> <p>⑫ OPS SLOT Slot for installing the optional OPS module.</p> |
|--|---|

2.3. Remote Control

2.3.1. General Functions



① [POWER] POWER button

Turn the display on or put the display to standby.

Long press POWER button until power is off.

② [PLAY] buttons

Control playback of media files.

③ [USB] button

Go to USB source.

④ [CMS] button

Go to CMS app.

⑤ [Time] button

Go to Time Setup OSD.

⑥ [FORMAT] FORMAT button

Reserved.

⑦ [HOME] HOME button

Go to Android Launcher first widgets.

⑧ [FUNCTION] FUNCTION button

Reserved.

⑨ [COLOR] buttons

Reserved.

⑩ [Source Button] Source Button

Choose input source.

⑪ [Settings Button] Settings Button

Access the OSD menu.

⑫ [NAVIGATION] buttons

Up, down, left and right operation key.

⑬ [OK] button

Confirm an entry or selection.

⑭ [INFO] INFO button

Show Information OSD.

⑮ [OPTIONS] button

Access currently available options, for Media Input/PDF Player.

⑯ [VOLUME] button

Adjust volume level.

⑰ [BACK] button

Return to the previous page or exit from the previous function.

⑱ [MUTE] button

Mute or restore volume.

⑲ [Channel] button

Reserved.

⑳ [Number] button

Input figures or text.

㉑ [RETURN] button

Reserved.

㉒ [HELP] Button


Reserved.

2.3.2. Inserting the Batteries in the Remote Control

The remote control is powered by two 1.5V AAA batteries.

To install or replace the batteries:

1. Press and then slide the cover to open it.
2. Insert the batteries with the correct polarity (+) and (-).
3. Replace the cover.



CAUTION:

Incorrect use of batteries may cause leakage or explosion. Be sure to follow the instructions below:

- Insert “AAA” batteries with the correct polarity (+ and -).
- Do not mix battery types.
- Do not use a new battery with a used one together. Otherwise, it may cause leakage or shorten the life of the batteries.
- Remove the dead batteries immediately to avoid battery leakage in the battery compartment. Do not touch exposed battery acid, as it may cause injury to your skin.

NOTE:

Remove the batteries from the battery compartment when not using for an extended period of time.

2.3.3. Handling the Remote Control


- Do not drop or apply shock to the remote control.
- Do not allow any liquid to get inside the remote control. If water has entered the remote control, wipe the remote control with a dry cloth immediately.
- Do not place the remote control near heat and steam sources.
- Do not attempt to disassemble the remote control, unless you need to place batteries in the remote control.

2.3.4. Operating Range of the Remote Control

Point the top front of the remote control to the remote sensor on the display when you press the buttons.

NOTE:


The remote control may not function properly when the remote control sensor on the display is under direct sunlight or strong illumination, or when there is an object between the remote control and the remote sensor of the display.



3. Connecting External Equipment


3.1. Connecting External Equipment (DVD/VCR/VCD)

3.1.1. Using HDMI Video Input




3.2. Connecting a PC


3.2.1. Using HDMI Input




3.2.2. Using VGA Input




3.2.3. Display Control Connection




3.2.4. Using Network Interface



3.2.5. Connecting an External Audio Device




3.3. Connect USB




4. Operation

4.1. Media Player Introduction


1. The front page of the media player, this page contains three items: "Play", "Compose" and "Settings".
Play: choose to play the playlist.
Compose: edit playlist.
Settings: set the playback content.



2. Select the "Play" on the home page, and you should first select a playlist to play between File 1 and File 7. The pencil icon represents the playlist is non-empty.




3. Select the "Compose" on the home page, and you should first select a playlist to edit between File 1 and File 7. The pencil icon represents the playlist is non-empty.




4. If you select the empty playlist, the application will guide you to choose media sources.

All media files should be located in the root directory. For example:


- Video /root/movies/
- Photos /root/pictures/
- Music /root/music/



5. You can edit or delete non-empty playlists, just select the required playlist with pencil icons.




6. You could rename the playlist, just input new name after pressing the "OPTIONS" key on the remote control.




7. After you start editing the playlist, you will see the following screen.
Source - storage device files.
Playlist - playlist file.
There are 4 icons which map to the keys of remote controller.
Option key - start rolling.
Play key - play media files.
Info key - media information display.
OK key - select / deselect files.

7-1 in a scroll bar can help you to perform the following items:

- Select all: Select all the storage files.
- Delete all: Delete all the playlist files.
- Add/Remove: Update from the playlist.
- Sort: Sort playlists.
- Save/Abort: save or abort the playlist.
- Back: return.




8. If you are in a scroll bar and select "Sort", you can change the order of files one by one.




9. In choosing the desired file information and press button, you can get detailed information.





10. In choosing the desired file and pressing the play button, you can directly play media files.



11. If you make a playlist containing all of the image files, the application will ask you if you want to play background music while playing the video.



12. On the first page of "Settings", this page contains three parts: "Repeat Mode", "Slideshow Effect" and "Effect Duration".
Repeat Mode: playback mode.
Slideshow Effect: photo slide effect.
Effect Duration: photo duration effect.




4.2. PDF Reader Play

1. Home page of PDF app, this page has three items: “Play”, “Compose” and “Settings”.


Play: select playlist to play.

Compose: edit playlist.

Settings: set play properties.




2. Select “Play” on home page, first you should choose one playlist to play between File 1 and File 7.
The pencil icon means the playlist is non-empty.




3. Select “Compose” on home page, first you should choose one playlist to edit from File 1 and File 7.
The pencil icon means the playlist is non-empty.


4. If an empty playlist is chosen, the app will guide you to select the media source.
All media files should be placed in root directory.
For example,
- pdfs in/root/pdf/



5. You could edit or delete a non-empty playlist, just choose the desired playlist which is with pencil icon.



6. You could rename the playlist, just input new name after pressing the “OPTIONS” key on the remote control.



7. Once you start to edit a playlist, you will see below screen.

Source - files in storage.

Playlist – files in playlist.

There are 4 icons which map to the keys of remote controller.

Option key – launch slide bar.


Play key – play media file.

Info key – show media info.


OK key – select/unselect file.

7-1. In the slide bar, it helps you to do the followings:

- Select all: select all storage files.
- Delete all: delete all playlist files.
- Add/Remove: update playlist from source.
- Sort: sort playlist.
- Save/Abort: save or abort the playlist.
- Back: return.




8. If you choose “Sort” in the sidebar, you can change the order of files one by one.



9. Select “Settings” on home page, this page has two parts, “Repeat Mode” and “Effect Duration”.


Repeat Mode: play mode.

Effect Duration: photo effect duration.




4.3. U player Autoplay Instructions


1. U disk, the format must be FAT32, and only one partition can not be partitioned, the capacity can not exceed 32G.
2. Create a SuperU folder in the root directory of the U disk, and place the video or image you want to play in this folder.




3. Connect your USB device to the USB port on the display.
4. Press the remote control [⚙️] setting button to enter the OSD menu.




5. Press [➡️] right button to select advanced options.



6. Press [⏮️] down button to select UPlayer setting, press [OK] to enter UPlayer setting.




7. Press [⏮️/➡️] left/right button to switch on or off.




8. Repeat time, to set how long to play a picture, it does not affect video playback. The video playback will play the next program after the end of previous program.
9. When completed the above settings, the U disk will start playing the content automatically after re-plugged or re-booted.

4.4. U Disk Files Playback and Copy Instructions


1. U disk, the format must be FAT32, and only one partition can not be partitioned, the capacity can not exceed 32G.
2. Connect your USB device to the USB port on the display.
3. Select the USB flash drive icon and click **OK** to enter the file browser.




4. Press [**▲/▼**] up/down button to select video or picture you want to play.




5. Click the [**OK**] button to open directly. Press [**≡**] **OPTIONS** button to pop up the option menu.
6. Users can choose to play, copy or move, etc., for example, if you want to copy a file to the internal storage Movies folder, select copy and it will pop up "Destination".



7. After selecting the directory to copy to, press the [**◀/▶**] left / right buttons on the remote control to select Paste or Cancel, as shown below.



8. Press the [**OK**] button to complete the file copy.



4.5. App Customization

The user can set the client-source application programs.

NOTES:


1. Display the app installed by users only.
2. Do not display the app pre-installed by the system.

5. OSD Menu


An overview of the On-Screen Display (OSD) structure is shown below. You can use it as a reference for further adjustment of your display.

5.1. Navigating the OSD Menu

5.1.1. Navigating the OSD Menu Using the Remote Control



1. Press [] button on the remote control to display the OSD menu.



2. Press [] or [] button to select the item to adjust.
3. Press [**OK**] button to enter the submenu.
4. In the submenu, press [] or [] button to toggle between items, press [] or [] button to adjust the settings. If there is a submenu, press [**OK**] button to enter the submenu.

5. Press [] button to return to the previous menu.

5.1.2. Navigating the OSD Menu Using the Display's Control Buttons

1. Press [**MENU**] button to display the OSD menu.
2. Press [] or [] button to select the item to adjust.
3. Press [**MENU**] button to enter the submenu.
4. In the submenu, press [] or [] button to toggle between items, press [] or [] button to adjust settings. If there is a submenu, press [**MENU**] button to enter the submenu.
5. Press [**INPUT**] button to return to the previous menu.

5.2. Operation on the OSD Menu

| Column 1 | Column 2 | Column 1, 3 | Column 2, 3 or Column 2, 2 | Remarks |
|----------|--------------------|--------------------|---------------------------------|--|
| Picture | Picture Mode | Mode | Airport and train station | |
| | | | Hotel and convenient store | |
| | | | Dining and clothing | |
| | | | Security control and monitoring | |
| | | | Office | |
| | | | Outdoor | |
| | | | Customize | |
| | | Black Level | [0 ... 100] | |
| | | Brightness | [0 ... 100] | |
| | | Contrast | [0 ... 100] | |
| | | Dynamic Brightness | On/Off | Available only in the HDMI1/2 Source |
| | Advanced | VGA | Auto Adjust | |
| | | | Horizontal [0...100] | |
| | | | Vertical [0...100] | |
| | | | Clock [0...100] | |
| | | | Phase [0...100] | |
| | | Eyes Protect Mode | On/Off | |
| | | Color temp | Standard | |
| | | | Cool | |
| | | | Warm | |
| | | Over scan | On/Off | Available when PC mode = Video. |
| | | RGB Range | Auto | |
| | | | Full Range | |
| | | | Limited Range | |
| | | PC Mode | PC/Video/Auto | You can use this function to change the PC timing or video timing. |
| | Screen Orientation | 0,90,180,270 | | |

| | | | | |
|-------|-----------------|------------------|---------------|---|
| Sound | Sound Mode | Standard | | Audio cannot be set through restoring settings. |
| | | News | | |
| | | Music | | You can reset audio by Restore Default. |
| | | Movie | | |
| | Audio Source | HDMI | | Available only in the HDMI Source |
| | | Line in | | |
| Lock | Advanced | Balance | [-50 ... +50] | |
| | | Volume | [0 ... 100] | |
| | Key Lock | Off | | Default password: 0000 |
| | | Type Password | | Switch Key Lock On: |
| | Change Password | Current Password | | Step 1: Lock the remote control, button and mouse operation functions after 5s if there is no operation. |
| | | New Password | | Step 2: After the functions are locked, press the "Set" button on the remote control for 5 seconds, and then enter the correct password in the password dialog box to unlock the functions. |
| | | Confirm Password | | |
| | | Cancel/OK | | Step 3: Repeat step 1 after operation. Or press the "Set" button on the remote control to turn off lock function thoroughly. |

| | | | | |
|------|------------|---------------|--|--|
| Time | Time Setup | Time Setting | Date Picker | Set Year/Month/Date Time: Minute |
| | | Shutdown Time | Repeat | OFF/Once/Everyday/ Workday |
| | | | Time | Set the time. |
| | | Power Time | Repeat | OFF/Once/Everyday/ Workday |
| | | | Time | Set the time. |
| | | | Source | VGA/HDMI1/ HDMI2/OPS/home/ PDF/Media/CMS/ Customer/Last Source |
| | | | File Number [1 ... 7] | It depends on the source(=MEDIA/ PDF). |
| | | Sleep Time | Off/10min/20min/30min/60min/90min/120min/180min/240min | |
| | | Auto Sleep | Off/5S/10S/30S/60S | |
| | | Time Sync | Network Time/Off | |
| | | Time Zone | London/Calcutta/ Harare/Karachi/ Brazzaville/ Beirut/Jerusalem/ Tehran/Baghdad/ Ulaanbaatar/ Damascus/Sydney/ Paris/Rome/ London/Dubai/ Tokyo | |

| | | | | |
|----------|----------------|----------------|--|--|
| Advanced | Language | English | | |
| | | 中文（中国） | | |
| | HDMI Version | HDMI1.4 | | |
| | | HDMI2.0 | | |
| | Power On Mode | Power On | | |
| | | Standby | | |
| | | Last Status | | |
| | Boot On Source | Switch | On/Off | |
| | | Boot On Source | HDMI1/HDMI2/OPS/PDF/Media/CMS/Customer/Last Source/VGA/USB | 1. When SCHEDULE is set with startup time, but the startup time has not arrived yet, boot the device according to the signal source set in the "Boot On Source". 2. If the source is set in USB, the booting page is the "U disc homepage". |
| | | Play List | Play list [1 ... 7] | 1.Play List is grayed 2.When the Boot On Source is PDF or Media Player, Play List is available. |
| | Boot Wake | UART Wake | On/Off | When UART wake = On, RC off or power saving can either be waken up by UART wake. |
| | | HDMI/VGA Wake | On/Off | When HDMI Wake = On, and the current source is HDMI1/2, power saving and the current HDMI source are waken up with signals. |
| | RS322 Control | RS322 Control | On/Off | |
| | | RS322 Source | RS232/OPS | |
| | Pixel Shift | On/Off | | |

| | | | | |
|----------|-----------------|-----------------|----------------|---|
| Advanced | Uplayer Setting | Switch | On/Off | <p>1. When Uplayer Setting switch on, Boot On Source is grayed, the setting is unavailable.</p> <p>2. Supported file name: SuperU</p> <p>3. To play content in UPlayer, the system will cut the signal source to USB, and stay at the USB source when plugging and unplugging the USB flash drive.</p> <p>4. Pivot jump to UPlayer when booting, the priority is higher than the source specified by the schedule boot.</p> |
| | | Repeat Time | 8S/16S/24S/32S | <p>Supported file type:</p> <p>1. Photo: ".png", ".jpg"</p> <p>2. Video: ".dat", ".vob", ".ts", ".mkv", ".mov", ".3gp", ".flv", ".webm", ".wmv", ".asf", ".mp4", ".avi", ".mpg".</p> |
| | Restore | Restore Default | Cancel/OK | System Reset |

NOTES:

- To wake up PD in the HDMI source, you can set HDMI wakeup "On".
- This product supports timed shutdown and timed startup functions. Refer to the "Shutdown time/Startup time" in the upper table for details.
- Some options may vary for different signals, please subject to the actual machine.

6. Compatibility of the USB Device

Format of the USB multi-media coder-decoder

| Video decoding | | | | | | |
|----------------|---------------------|----------------------------|----------|--------|---------|--|
| Type | Video coder-decoder | Container | Decoding | Coding | Channel | Remarks |
| MPEG1/2 | MPEG1/2 | File format: VOB | V | | | Supported size in a range from 48x48 pixels to 1920X1080 pixels Max. frame rate:30fps Max. bit rate: 80Mbps Audio coder-decoder: MP2, MP3 |
| MPEG-4 | MPEG4 | File format: MKV, MP4, 3GP | V | | | Supported picture size in a range From 48x48 pixels 1920x1080 pixels Max. frame rate:30fps Max. bit rate: 38.4Mbps Audio coder-decoder: MP2, MP3, AAC, (1) MS MPEG4 v1/v2/v3 is not supported. (2) GMC (global movement compensation) is not supported. |
| H.263 | H.263 | File format: 3GP, MP4 | V | | | Supported picture size: SQCIF(128x96), QCIF(176x144), CIF(352x288), 4CIF(704x576) Max. frame rate: 30fps Max. bit rate: 38.4Mbps Audio coder-decoder: MP3 (1) Not support H.263+ |

Compatibility of the USB device

| | | | | | | |
|-------|-------|----------------------------------|---|--|--|--|
| H.264 | H.264 | File format: MKV, MP4, 3GP | V | | | Supported picture size: from 48x48 pixels to 1920x1080 pixels Max. frame rate:30fps Max. bit rate: 57.2Mbps Audio coder-decoder: MP2, MP3, AAC (1) Not support MBAFF |
| VC-1 | VC1 | File format: MKV | V | | | Supported picture size: frame 48x48 pixels to 1920x1088 pixels Max. frame rate:30fps Max. bit rate: 45Mbps Audio coder-decoder: MP2, MP3, AAC, WMA |

Audio decoding

| Type | Audio coder-decoder | Container | Decoding | Coding | Channel | Remarks |
|---------------------|---|-----------------------|----------|--------|---------|--|
| MPEG audio | MPEG1/2/2.5 Audio Layer1/2/3 | Decode: MP1, MP2, MP3 | V | | 2 | Bit rate: 8Kbps~320Kbps, CBR and VBR Sampling rate: 8KHz~48KHz |
| Windows Media Audio | WMA version 4,4.1, 7, 8, 9, wmapro | Decode: WMA | V | | 2 | Bit rate: 8Kbps~320Kbps Sampling rate: 8KHz~48KHz Do not support WMA Pro non-destructive and MBR |
| AAC audio | MAIN, ADIF, ATDS Header AAC-LC and AAC-HE | File format: AAC, M4A | V | | 5.1 | Bit rate: N/A Sampling rate: 8KHz~48KHz |

Picture decoding

| Type | Picture coder-decoder | Picture | Decoding | Coding | Channel | Remarks |
|------|-----------------------|------------------------|----------|--------|---------|--|
| JPEG | JFIF file format 1.02 | File format: JPG, JPEG | V | | | Decode: Resolution ratio 48X48 to 8176X8176 (1) Row-by-row scanning is not supported. (2) Software supports SRGB JPEG. (3) Software supports Adobe RGB JPEG. |
| BMP | BMP | File format: BMP | V | | | Supported max. picture size: 4096x4096 pixels |
| GIF | GIF | File format: GIF | V | | | No limit in resolution ratio |
| PNG | PNG | File format: PNG | V | | | No limit in resolution ratio |

NOTES:

- If the standard bite rate/frame rate of the contents is higher than the compatible frames/second listed in the above table, audio or video may not work.
- Video contents with a bit rate or frame rate higher than the designated rate in the above table may result in discontinuation of video during display.

7. Input Mode

HDMI computer mode

| Standard Resolution | Active Resolution | | Refresh Rate | Pixel Rate | Aspect Ratio |
|---------------------|-------------------|---------|--------------|------------|--------------|
| | H Pixel | V Lines | | | |
| VGA | 640 | 480 | 60 Hz | 25.175 MHz | 4:3 |
| | | | 75 Hz | 31.5 MHz | |
| WVGA | 720 | 400 | 70 Hz | 28.32 MHz | 4:3 |
| SVGA | 800 | 600 | 60 Hz | 40 MHz | 4:3 |
| XGA | 1024 | 768 | 60 Hz | 65 MHz | 4:3 |
| WXGA | 1152 | 870 | 75 Hz | 100 MHz | 4:3 |
| WXGA | 1280 | 720 | 60 Hz | 74.5 MHz | 5:3 |
| SXGA | 1280 | 1024 | 60 Hz | 108 MHz | 5:4 |
| UXGA | 1600 | 900 | 60 Hz | 108 MHz | 4:3 |
| UXGA | 1680 | 1050 | 60 Hz | 146.25 MHz | 16:10 |
| HD1080 | 1920 | 1080 | 60 Hz | 148.5 MHz | 16:9 |
| 4K2K | 3840 | 2160 | 60 Hz | 594 MHz | 16:9 |

Recommended resolution ratio: 3840x2160@60Hz

HDMI video mode

| Standard Resolution | Active Resolution | | Refresh Rate | Pixel Rate | Aspect Ratio |
|---------------------|-------------------|---------|--------------|------------|--------------|
| | H Pixel | V Lines | | | |
| 3840 x 2160 P 60 Hz | 3840 | 2160 | 60 Hz | 594 MHz | 16:9 |
| 3840 x 2160 P 30 Hz | 3840 | 2160 | 30 Hz | 297 MHz | 16:9 |
| 3840 x 2160 P 25 Hz | 3840 | 2160 | 25 Hz | 297 MHz | 16:9 |
| 3840 x 2160 P 24 Hz | 3840 | 2160 | 24 Hz | 297 MHz | 16:9 |
| 1080 P 59.94/60 Hz | 1920 | 1080 | 60 Hz | 148.5 MHz | 16:9 |
| 1080 P 50 Hz | 1920 | 1080 | 50 Hz | 148.5 MHz | 16:9 |
| 1080 P 29.97/30 Hz | 1920 | 1080 | 30 Hz | 74.25 MHz | 16:9 |
| 1080 P 25 Hz | 1920 | 1080 | 25 Hz | 74.25 MHz | 16:9 |
| 1080 P 23.97/24 Hz | 1920 | 1080 | 24 Hz | 74.25 MHz | 16:9 |
| 1080 I 59.94/60 Hz | 1920 | 1080 | 60 Hz | 74.25 MHz | 16:9 |
| 1080 I 50 Hz 16:9 | 1920 | 1080 | 50 Hz | 74.25 MHz | 16:9 |
| 720 P 50 Hz 16:9 | 1280 | 720 | 50 Hz | 74.25 MHz | 16:9 |
| 720 P 59.94/60 Hz | 1280 | 720 | 60 Hz | 74.25 MHz | 16:9 |
| 576 I 50 Hz 4:3 | 720 | 576 | 50 Hz | 13.5 MHz | 4:3 |
| 576 I 50 Hz 16:9 | 720 | 576 | 50 Hz | 13.5 MHz | 16:9 |
| 480 I 59.94/60 Hz | 720 | 480 | 60 Hz | 13.5 MHz | 4:3 |
| 576 P 50 Hz 4:3 | 720 | 576 | 50 Hz | 27 MHz | 4:3 |
| 576 P 50 Hz 16:9 | 720 | 576 | 50 Hz | 27 MHz | 16:9 |
| 480 P 59.94/60 Hz | 720 | 480 | 60 Hz | 27 MHz | 16:9 |
| 480 P 59.94/60 Hz | 720 | 480 | 60 Hz | 27 MHz | 4:3 |

PC mode

| Standard Resolution | Active Resolution | | Refresh Rate | Pixel Rate | Aspect Ratio |
|---------------------|-------------------|---------|--------------|------------|--------------|
| | H Pixel | V Lines | | | |
| VGA | 640 | 480 | 60 Hz | 25.175 MHz | 4:3 |
| | | | 75 Hz | 31.5 MHz | |
| WVGA | 720 | 400 | 70 Hz | 28.32 MHz | 4:3 |
| SVGA | 800 | 600 | 60 Hz | 40 MHz | 4:3 |
| XGA | 1024 | 768 | 60 Hz | 65 MHz | 4:3 |
| WXGA | 1152 | 870 | 75 Hz | 100 MHz | 4:3 |
| WXGA | 1280 | 720 | 60 Hz | 74.5 MHz | 5:3 |
| SXGA | 1280 | 1024 | 60 Hz | 108 MHz | 5:4 |
| UXGA | 1600 | 900 | 60 Hz | 108 MHz | 4:3 |
| UXGA | 1680 | 1050 | 60 Hz | 146.25 MHz | 16:10 |
| HD1080 | 1920 | 1080 | 60 Hz | 148.5 MHz | 16:9 |
| WXGA | 1366 | 768 | 60 Hz | 85.75 MHz | 16:9 |

8. Cleaning and Troubleshooting

8.1. Cleaning

Caution When Using the Display

- Do not bring your hands, face or objects close to the ventilation holes of the display. The top of the display is usually very hot due to the high temperature of exhaust air being released through the ventilation holes. Burns or personal injuries may occur if any body parts are brought too close. Placing any object near the top of the display could also result in heat related damage to the object as well as the display itself.
- Be sure to disconnect all cables before moving the display. Moving the display with its cables attached may damage the cables and thus cause fire or electric shock.
- Disconnect the power plug from the wall outlet as a safety precaution before carrying out any type of cleaning or maintenance procedure.


Front Panel Cleaning Instructions

- The front of the display has been specially treated. Wipe the surface gently using only a cleaning cloth or a soft, lint-free cloth.
- If the surface becomes dirty, soak a soft, lint-free cloth in a mild detergent solution. Wring the cloth to remove excess liquid. Wipe the surface of the display to remove dirt. Then use a dry cloth of the same type to dry.
- Do not scratch or hit the surface of the panel with fingers or hard objects of any kind.
- Do not use volatile substances such as insect sprays, solvents and thinners.

Cabinet Cleaning Instructions

- If the cabinet becomes dirty, wipe the cabinet with a soft, dry cloth.
- If the cabinet is extremely dirty, soak a lint-free cloth in a mild detergent solution. Wring the cloth to remove as much moisture as possible. Wipe the cabinet. Use another dry cloth to wipe over until the surface is dry.
- Do not allow any water or detergent to come into contact with the surface of the display. If water or moisture gets inside the unit, operating problems, electrical and shock hazards may result.
- Do not scratch or hit the cabinet with fingers or hard objects of any kind.
- Do not use volatile substances such as insect sprays, solvents and thinners on the cabinet.
- Do not place anything made from rubber or PVC near the cabinet for any extended periods of time.

8.2. Troubleshooting

| Symptom | Possible Cause | Remedy |
|--|---|--|
| No picture is displayed | <ol style="list-style-type: none"> 1. The power cord is disconnected. 2. The main power switch on the back of the display is not switched on. 3. The selected input has no connection. 4. The display is in the standby mode. | <ol style="list-style-type: none"> 1. Plug in the power cord. 2. Make sure that the power switch is switched on. 3. Connect a signal connection to the display. |
| Interference displayed on the display or an audible noise is heard | Caused by surrounding electrical appliances or fluorescent lights. | Move the display to another location to see if the interference is reduced. |
| Color is abnormal | The signal cable is not connected properly. | Make sure that the signal cable is attached firmly to the back of the display. |
| Picture is distorted with abnormal patterns | <ol style="list-style-type: none"> 1. The signal cable is not connected properly. 2. The input signal is beyond the capabilities of the display. | <ol style="list-style-type: none"> 1. Make sure that the signal cable is attached firmly. 2. Check the video signal source to see if it is beyond the range of the display. Please verify its specifications with this display's specification section. |
| Can hear sound, but no picture | Source signal cable is connected improperly. | Make sure that both video inputs and sound inputs are correctly connected. |
| Can see picture but no sound is heard | <ol style="list-style-type: none"> 1. Source signal cable is connected improperly. 2. Volume is turned all the way down. 3. {Mute} is turned on. 4. No external speaker is connected. | <ol style="list-style-type: none"> 1. Make sure that both video inputs and sound inputs are connected correctly. 2. Press [+] or [-] button to hear sound. 3. Switch MUTE off by using the  button. 4. Connect external speakers and adjust the volume to a suitable level. |

Cleaning and Troubleshooting

| | | |
|---|---|---|
| Some picture elements do not light up | Some pixels of the display are off. | This display is designed using an extremely high level of precision technology: however, sometimes some pixels of the display may not display. This is not a malfunction. |
| After-Images can still be seen on the display after the display is powered off. (Examples of still pictures include logos, video games, computer images, and images displayed in 4:3 normal mode) | A still picture is displayed for an over extended period of time. | Do not allow a still image to be displayed for an extended period of time as this can cause a permanent after-image to remain on the display. |

9. Technical Specifications

Display:

| Item | Specifications |
|---------------------------|----------------------------|
| Screen Size (Active Area) | 64.5 inches |
| Aspect Ratio | 16:9 |
| Number of pixels | 3840 (H) x 2160 (V) |
| Pixel pitch | 0.372 (H) x 0.372 (V) [mm] |
| Displayable colors | 1.07B (8bits+FRC) |
| Brightness (Typ.) | 400 cd/m ² |
| Contrast ratio (Typ.) | 1200:1 |
| Viewing angle | 178 degrees |

General:

| Item | Specifications |
|--|----------------------------|
| Internal memory | 8GB eMMC |
| Power | 100 - 240V~, 50 - 60Hz, 4A |
| Power Consumption (Max) | 280 W |
| Power Consumption (Typ.) | 170 W |
| Power Consumption (Standby & Off) | <0.5 W |
| Dimensions (Without Stand) [W x H x D] | 1459 x 835 x 82 mm |

Environmental Condition:


| Item | | Specifications |
|-------------|------------------|-------------------------------|
| Temperature | Operational | 5 ~ 40°C |
| | Storage | -20 ~ 60°C |
| Humidity | Operational | 20 ~ 80% RH (No condensation) |
| | Storage | 10 ~ 90% RH (No condensation) |
| Altitude | Operational | 0 ~ 3,000 m |
| | Storage/Shipment | 0 ~ 9,000 m |

Internal Speaker:

| Item | Specifications |
|--------------------|-----------------|
| Number of Speakers | 2 |
| Input | 12 W X 2 |
| Impedance | 8 Ω |
| Frequency Response | 160 Hz ~ 13 KHz |

2019 © All rights reserved.

Specifications are subject to change without notice.



Q41G65M166101B